Instructions For Assembling Gulf Shore Base Cabinets

Photos show cordless screw driver, a regular screw driver can be used as well.

Direct Kitchen Source • www.GulfShoreCabinets.com
Tel: 888-677-6234 • Fax: 386-677-9636

Tightening speed lock fasteners on one of the Side Panels

1. Remove parts from the box and lay them out in front of you so that you can find and identify them.

2. Find the "Face-Frame" (labeled by an "A" sticker), and lay it face-down on a soft, flat working surface.

3. Make sure the speed lock fastener on the cabinet's Side Panels(B) are opened up and insert the two Side Panels intot he grooves of the Face-Frame(A). Make sure the speed lock fastener connectors are lined up and fitting together, and the Side Panels are fitting into the grooves of the Face-Frame, then, using a screwdriver, tighten screws in SLF.

4. Making sure finished side is facing up, insert the Bottom Panel(C) into the grooves of the Side Panels(B) and Face Frame(A).

Inserting Bottom Panel

5. With the finished side facing inside the cabinet, put the Back Panel(D) onto the Side Panels(B) and over the Bottom Panel(C).

The top of the Back Panel should be flush with the top of the Side Panels. Make sure all the panels fit together properly and screw SLF together.

6. Position the Toe Kick(F) at the bottom and front of the SIde Panels, secure with screws into SLF.

7. Now stand the cabinet upright. Place each of the 4 plastic Corner Bracers in each top corner of the cabinet using the 8 medium-sized screws included.

Positioning Back Panel

Positioning Toe Kick onto Side Panels

Installing Nylon Corner Bracers

Instructions For Assembling Gulf Shore Base Cabinets

Photos show cordless screw driver, a regular screw driver can be used as well.

Inserting Drawer Side onto Drawer Front

Drawer Assembly:

8. Insert the Drawer Sides(B) into the Drawer Front(A), attach with screws provided.

Slide the Drawer Bottom(D), finished side up, into the grooves in the Drawer Sides and Drawer Front, place the Drawer Back(C) on the Drawer Sides and attach with screws provided.

Make sure the Drawer Bottom fits into the groove in the Drawer Back before locking.

Assemble with Screws Provided

Inserting Drawer Bottom into Drawer Slides

Tighting Speed Lock Fastener on Drawer Side and Drawer Back

Positioning Drawer Slide through Drawer Opening

9. Attach the plastic Drawer Slide Holders onto the back end of the Drawer Slides (the back end would be the end opposite the end with the wheel).

Insert the Drawer Slide through the drawer opening in the Face-Frame and insert the Drawer Slide Holder into the pre-drilled holes in the Back Panel. The Drawer Slides should be positioned so that the wheel (roller) is toward the bottom and facing inside.

Instructions For Assembling Gulf Shore Base Cabinets

Photos show cordless screw driver, a regular screw driver can be used as well.

Fastening front of Drawer Slide to Face-Frame

Secure Drawer Slides to back of cabinet through pre-drilled holes.

Tighten the front of the Drawer Slide to the pre-drilled holes in the side of the Face-Frame using the smallest screws included.

Repeat the steps and install the other Drawer Slide. Install the completed drawer into the cabinet, and check to see that it opens and closes well. You may adjust the vertical location of the Drawer Slide Holders for best operations, if neccessary.

10. Insert Shelf Clips into the pre-drilled holes in the Side Panels at the desired height and slide in the shelf making sure the finished edge faces out.

Check that drawer opens and closes well.

Installing Shelf in Cabinet

Finished Gulf Shore Cabinet